

SELGIENE EXTREME

C500

PRODUCT INFORMATION

UNPERFUMED BACTERICIDAL, VIRUCIDAL CLEANER CERTIFIED TO EN STANDARDS: 1276, 1467

optimal disinfection for use in healthcare, catering and high risk applications. Kills Norovirus, E. Coli, Swine Flu, HIV, Hepatitis C, MRSA & Clostridium difficile Passes EN 1276, 13704, 1650, 14476 & 14675 Manufactured in the UK to ISO 9001, 14001 & 18001

Features : Bactericidal, Highly Concentrated, Unperfumed

Benefits : Aluminium Safe, Free Rinsing, Stainless Steel Safe

Key Category : Disinfectant

Product Appearance	Clear thin liquid, Pink	Specific Gravity : 1.034
Perfume	Unfragranced	pH 10
Pack = 5LX2	Dimensions 185mm (w) x 278mm (d) x 280mm (h)	Gross Weight :10.93 kg
Unit = 5L(BOT)	Dimensions 185mm (w) x 134mm (d) x 283mm (h)	Gross Weight : 5.47 kg

RECOMMENDED TASKS FOR THIS PRODUCT

CATEGORY	TASK DESCRIPTION	DILUTION	PPE	RCR
GENERAL CLEANING	HIGH LEVEL HYGIENE	1 : 40 (2.5%)	Gloves	Good
BAR AND CELLAR	CELLAR FLOOR CLEANING	1 : 40 (2.5%)	Gloves, Boots	Good
GENERAL CLEANING	HARD SURFACE DISINFECTING	1 : 40 (2.5%)	Gloves	Good
GENERAL CLEANING	SPRAY AND WIPE HARD SURFACE CLEANING	1 : 10 (10%)	Gloves	Good
GENERAL CLEANING	SPRAY AND WIPE SANITISING (CLEAN & DISINFECT)	1 : 10 (10%)	Gloves	Good
CATERING	DAMP MOPPING	1 : 40 (2.5%)	Gloves, Boots	Good
FLOOR CARE	CLEANING & DISINFECTING (MOPPING ONLY)	1 : 40 (2.5%)		Good
FLOOR CARE	CLEANING (MOPPING ONLY)	1 : 40 (2.5%)	Gloves, Boots	Good
GENERAL CLEANING	HIGH LEVEL HYGIENE (SPRAY AND WIPE)	1 : 10 (10%)	Gloves	Good

Selden Research - Promoting Safe, Sustainable and Successful Cleaning

This product may be used for other tasks. You can perform REACH compliance audits for these on our Hygiene and Safety Management website www.cleanfm.com

NEAT CHEMICAL INFORMATION



Brand	SELDEN
Code	C500
Unit	5L(BOT)
Stock ID	C500-5LX2-SELDEN

HAZARD INFORMATION

DANGER

Causes skin irritation. Causes serious eye damage.



PERSONAL PROTECTION EQUIPMENT



PRECAUTION PHRASES

Keep out of reach of children. Wash hands thoroughly after handling. Wear eye protection, protective gloves. IF ON SKIN: Wash with plenty of soap and water. IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing. Get immediate medical attention. Take off contaminated clothing and wash before reuse.

NEAT CHEMICAL RISK / ECO IMPACT

RcR (Risk Characterisation Rating)



(Environmental Impact Control) EIC

Above RcR and EIC are applicable for this chemical in its NEAT form. The IN USE values should be considered more 'significant'

CHECK FOR LATEST VERSION



This product has been audited and assessed as safe for a range of tasks. Use CleanFM to obtain task specific Chemical Safety Assessments www.cleanfm.com

REACH compliant

SELDEN RESEARCH LIMITED & CLEANFM



This Task Card was produced by our innovative chemical and hygiene management system - CleanFM <http://www.cleanfm.com> for more information

Selden Research Limited
Buxton, Derbyshire, SK17 9RZ
t: 01298 26226 | f: 01298 26540
e: info@selden.co.uk
w: www.selden.co.uk

